



**ALTEC PRODUCTS INC.**  
14050 Lincoln St. NE  
Suite 200  
Ham Lake, MN 55304  
763-785-9035  
Fax 763-785-9084  
www.ALTECPRODUCTS.com

# 05-07 C6 CORVETTE Wheel Spoke Faces

Patent Pending

1. Installing the *Spoke Faces* are easy and straight forward. No tools are required.

## 2. Cleaning Wheels:

Clean all wheels thoroughly with soap and water. Dry completely. Wipe each spoke using denatured alcohol or quality surface cleaner. Finish by using the supplied alcohol pad.

*Spoke Faces* are slightly narrower than spokes. **Note: Front Spoke Faces are shorter than rear.**

## 3. Installing *Spoke Faces*:

Practice installing *Spoke Faces* before removing tape liner. *Spoke Faces* are easily installed by aligning lug end of *Spoke Face* down into lug area. Carefully line up *Spoke Face* edge so equal amount of spoke shows as *Spoke Face* extends down toward end. (See Photo 1) Remove tape liner and install. Hold tape surface slightly off spoke to avoid tape contact. **Note:** When placing *Spoke Face* on spoke just lightly set into position. If *Spoke Face* is not aligned, lift off, and reposition. The tape used is a 3M VHB product, this tape is very aggressive. Do not press firmly if *Spoke Face* is not aligned properly.

**4. Activating 3M's VHB Tape:** After installing each *Spoke Face*, it is important to press firmly on part. Applying pressure by pressing down onto part will activate the VHB tape.

After all 20 *Spoke Faces* are installed, we recommend going back to first wheel and again press firmly on each *Spoke Face* to confirm each part had pressure applied for VHB tape to be activated.

5. Allow 24 hours before driving car for tape to gain full adhesion.



Product Patent Pending

Visit [www.altecproducts.com](http://www.altecproducts.com) for more Corvette accessories.

P/N 5130