



ALTEC PRODUCTS INC.
14050 Lincoln St. NE
Suite 200
Ham Lake, MN 55304
(763) 785-9035
Fax (763) 785-9084

05-ON CORVETTE

Custom-Fit Splash Guard

Installation Instructions

STEP 1 FRONT GUARDS:



Install mounting tabs on each guard using (2) 3/8" phillips machine screws and (2) kep nuts. Bend tab so it will lie flat on lower fender surface.

STEP 2 FRONT GUARDS:



Hold guard up to fender in position. Note: masking tape should be applied for marking holes to drill. Apply tape to fender well. Holding guard in a perfect level position, mark through holes in guard onto tape. A helper can assist in aligning per diagram A.

STEP 3 FRONT GUARDS:

Drill with a 9/64" bit (3) locations, 3 in fender well and 1 for lower bracket that lies flat against lower body. Remove masking tape. Install supplied (4) mounting screws. Make sure the guard edge fits flush with painted surface so not to rub paint.

STEP 1 REAR GUARDS:

NOTE: No mounting tabs are used on rear guards. Remove rear wheel. Repeat step 2 using tape and marking holes for drilling. Drill with a 9/64" bit (3) locations. The large 12 x 1 screws will be installed in the lower splash guard hole. This lower hole location is fastening into the black inner wheel well liner.

Installation is simple, however, for best results have a helper assist in aligning guards and drilling holes.

DIAGRAM A

