

ALTEC PRODUCTS



ALTEC PRODUCTS INC.

14050 Lincoln St. NE
Suite 200
Ham Lake, MN 55304
(763) 785-9035
Fax (763) 785-9084

AUTOCROSS CUSTOM-FIT SPLASH GUARD

ADDITIONAL INSTALLATION INSTRUCTIONS FOR

90-on CORVETTE ZR1

FRONT GUARD INSTALLATION

Locate lower (4) fender well fasteners. Remove bottom fastener, working upward, leave next fastener in place. Remove the next (2) fasteners. Position splashguard in place, reinsert top (2) larger sized fasteners. Use supplied 1" Phillips head sheet metal screw for bottom location. (See other Installation Instructions for bracket assembly, etc.)

REAR GUARD INSTALLATION

Locate lower (3) fasteners and remove. Position splash guard in place, and reinsert center lower fastener. Use supplied 1" Phillips head Sheetmetal screw. Screw fastener in upper & lower location. (Optional) Use supplied thin spacer behind guard in lower location. (See other Installation Instructions for bracket assembly, etc.)

Visit our website at www.altecproducts.com