

Installation Instructions for 91-96 Corvette Rear Lens Grills

Contact your
Corvette Accessory Dealer
for matching Rear Phantom
License Plate Frame

1. P/N 4110 fits 91-96 Corvette.
2. Remove screws from lens. Position grill and replace with supplied spacers and screws. (Note this side up arrow on back of grill).
3. Finish the installation by firmly pressing the snap-caps into place.

To clean use mild soap and water.



ALTEC PRODUCTS INC.

14050 Lincoln St. NE

Suite 200

Ham Lake, MN 55304

(763) 785-9035

Fax (763) 785-9084

www.altecproducts.com

DESIGNERS AND MANUFACTURERS OF QUALITY AUTOMOTIVE ACCESSORIES.