



ALTEC PRODUCTS INC.
14050 Lincoln St. NE
Suite 200
Ham Lake, MN 55304
(763) 785-9035
Fax (763) 785-9084
www.altecproducts.com

CORVETTE SILL COVER '88 - '96 (including ZR1)

NO DRILLING • 5 MINUTE INSTALLATION

1. BEFORE REMOVING DOUBLE BACK TAPE, POSITION SILL COVER ON PASSENGER SIDE.
2. LOCATE REAR HOLE IN SILL COVER OVER THE FORWARD MOST PHILLIPS HEAD SCREW ON CAR SILL. (THIS WILL BE THE INSTALLED POSITION.)
3. LIFT OFF SILL COVER AND REMOVE THE FORWARD MOST PHILLIPS SCREW FROM CAR SILL AND PEEL OFF DOUBLE BACK TAPE FROM SILL COVER.
4. POSITION SILL COVER IN CORRECT PLACEMENT AND PUSH DOWN INTO PLACE. PUT IN PROVIDED NEW PHILLIPS HEAD SCREW. PRESS FIRMLY ON AREAS OF TAPE TO COMPLETE.
5. INSTALLATION IS THE SAME FOR THE DRIVER SIDE.