

HUMMER H2 Rear License Frame

Installation Instructions

1. Remove snap caps from frame by popping them out from the rear.
(Caps are also easily removed from the front using a pointed object.)
2. Remove license plate from vehicle and clean.
3. Position the license plate behind the license plate frame. Install the short 1/4" - 20 x 1/2" stainless steel machine screws in the two lower holes of the license frame and license plate. Use supplied flat nuts and tighten.
4. Position license frame and plate assembly to the rear of HUMMER.
Use supplied stainless steel 14 x 3/4" screws to mount frame through remaining top two holes and into vehicle.
5. Finish by firmly pressing the snap caps back into place.



ALTEC PRODUCTS



ALTEC PRODUCTS INC.

14050 Lincoln St. NE
Suite 200
Ham Lake, MN 55304
(763) 785-9035
Fax (763) 785-9084

*Visit our website at www.altecproducts.com
for more HUMMER accessories.*

**DESIGNERS AND MANUFACTURERS
OF QUALITY AUTOMOTIVE ACCESSORIES.**