

# Installation Instructions for Altec Phantom Frame



1. P/N 411 fits 91-96 Corvette.  
P/N 412 fits 97-on Corvette.
2. Position frame on vehicle and secure with fasteners.
3. Finish the installation by firmly pressing the snap-caps into place.
4. Contact your Corvette Accessory Dealer for **NEW** matching Taillight Lens Grills by Altec.



## ALTEC PRODUCTS INC.

14050 Lincoln St. NE  
Suite 200  
Ham Lake, MN 55304  
(763) 785-9035  
Fax (763) 785-9084

- Visit our website at [www.altecproducts.com](http://www.altecproducts.com) for more Corvette accessories •

**DESIGNERS AND MANUFACTURERS OF QUALITY AUTOMOTIVE ACCESSORIES.**