

ALTEC PRODUCTS



ALTEC PRODUCTS INC.

14050 Lincoln St. NE
Suite 200
Ham Lake, MN 55304
(763) 785-9035
Fax (763) 785-9084

AUTOCROSS CUSTOM-FIT SPLASH GUARD

ADDITIONAL INSTALLATION INSTRUCTIONS FOR

91 - 96 CORVETTE

FRONT GUARD INSTALLATION

Remove (3) large upper fasteners and single small lower fastener from fender well. Re-insert (3) large fasteners, small lower fastener to be replaced with provided 1" Phillips head sheetmetal screw. Place provided spacer behind guard to even out surface of fender well where guard tightens against. Spacer to be used behind 1" Phillips screw only. (See other Installation Instructions for bracket assembly, etc.)

REAR GUARD INSTALLATION

Remove (3) lower fasteners. Re-insert large center fastener. Replace remaining (2) fasteners with provided 1" Phillips head sheetmetal screws. (See other Installation Instructions for bracket assembly, etc.)

Visit our website at www.altecproducts.com