

# HUMMER H2 Running Board Bracket Covers

Installation of the bracket covers is easy and straight forward.

1. **IMPORTANT:** Thoroughly clean running board brackets paying special attention to the surface that the chrome cover will mount to. (That is the flat forward facing surface.) Use glass cleaner such that no dirt, oily film or residue exists. Do not touch surface after cleaning.
2. Separate 4 driver side covers and 4 passenger side covers. (DRIVER or PASSENGER is marked on tape side of part.)
3. Before removing double back tape, position a chrome cover on a bracket. Note that cover can be positioned slightly up or down, allow cover to come down to hide weld bead.
4. Peel off double back liner from tape, position cover on bracket in correct placement and push down into place.



*Chrome bracket covers shown on passenger side of HUMMER.*

**ALTEC PRODUCTS**



**ALTEC PRODUCTS INC.**

14050 Lincoln St. NE  
Suite 200  
Ham Lake, MN 55304  
(763) 785-9035  
Fax (763) 785-9084

***Visit our website at [www.altecproducts.com](http://www.altecproducts.com)  
for more HUMMER accessories.***

**DESIGNERS AND MANUFACTURERS  
OF QUALITY AUTOMOTIVE ACCESSORIES.**