

# BOOMERANG®

F R A M E



## Installation Instructions for C8 Corvette



Separate finished frame face from back mounting plate by pulling the bottom of frame gently down and out to unlatch it from bottom snap-fit.

*Note that two hook-in tabs retain the frame face at the top, and two snap-fit tabs retain it at the bottom.*



Top hook-in tab detail



Bottom snap-fit tab detail



Mount back plate with two black Allen Head screws provided, with the molded in word "TOP" on the back-plate facing.



Align the hook-in tabs on back of the frame with slots at the top of the back plate, and gently pull down to engage them. Use the screw heads for proper placement reference.

Then simply snap in the bottom by pushing on the frame below the two lower screw cover features.



To remove the frame for cleaning or to update tabs, gently pull down and out to disconnect the lower snap-fit tabs as shown. Then slightly lift the frame to disengage top hook-in tabs.



Visit [AltecProducts.com](https://www.altecproducts.com) for distinctive accessories

**Altec Products** 14050 Lincoln St NE, suite 200, Ham Lake, MN 55304

**Call for information or to order 1-800-797-9035**