

Altec *Show n Go*™ license mount Installation 1997-04 C5 Corvette




Show Position




Go Position


Installation is easy using a Phillips screwdriver and 5/16" drill. The position of the stationary base plate screwed to the bottom of the bumper fascia determines the vertical angle of the license mount when it is in the up position. Slots in the base plate allow a final adjustment of this position after initial installation.



(A)



(B)



(C)

- 1) Jack up the left front of the car slightly to provide working room. Push the rubber nut into the bracket hole and push the top of the bracket in to the joint seam under the bumper as shown in (A). Have a helper position the base plate so it is one inch to the left of the bumper cut out, and the contact of the license mount with the bumper causes it to be in a 90 degree vertical position as shown in (B). When the plate is retracted, it must be to the left of the skid bar under the car. Mark two holes in center of slots as shown in figure (C).



- 2) Drill three 5/16 in. diameter holes in the marked locations.



- 3) Push the Rubber inserts into the drilled holes.

- 4) Install the base plate screws, leaving them loose enough to allow the base plate to be adjusted slightly back or forward to assure the license mount is in a 90 degree vertical position when the car is in a level position. About three screw driver turns on each fastener will expand and set the mounting rubber retaining nuts.

- 5) Install the license plate on the mount frame using the four #10 x 3/8 S/S phillips screws.

All major components are corrosion resistant and no regular maintenance is required.



Altec Products
14050 Lincoln NE
Ham Lake MN 55304
altecproducts.com

Copy Right Altec Products

Caution: The license mount must be in the vertical position when display is required by state law.

Product Patent Pending